
#### ---- LAB 4 ----

# FPGA Implementation (Nexys4)

洪銘佑 2018/11/28

# 實驗工具


- Nexys 4 DDR FPGA
- Vivado





# Nexys-4 DDR FPGA 開發板


- 請同學愛惜使用
- 本堂課程結束前請填寫財產借用單



















# Vivado教學-創建專案原始檔


- 按右鍵新增檔案
- 選擇檔案類型:
  constraints 可以新增.xdc檔
  design sources 可以新增.v檔
- · .xdc用來描述.
- · v與實體線路的連接關係
- · .v用來描述硬體行為
- 也可以從現有檔案匯




#### Vivado教學-創建專案原始檔




#### Vivado教學-加入專案原始檔




# Vivado教學-將程式寫入FPGA板



## Vivado教學-將程式寫入FPGA板



# Vivado教學-將程式寫入FPGA板



# 課堂練習


- · 將實驗壓縮包裡面的CO\_lab4example其中的專案寫入到 Nexys4中, 並了解其運作
- 修改 "top.v" 及 "Nexy4.xdc",新增2個指撥按鈕使其能運算加法、 乘法以及減法
- 向助教Demo結果
- 佔Lab4成績30


#### 作業驗收說明

- 把作業三完成的CPU及求最相近的兩個質數寫入Nexys4 需要包含:
  - 13個指撥作為輸入值(sw0~sw12)
  - 運算結果分別以前、後4個七段顯示器顯示
  - 使用reset重新計算新值
  - 說明文件(PDF)、CPU及求最相近兩個質數的專案
  - ※說明文件需包含:程式說明、如何控制顯示器
- 正確運算(50%)
- 能正確運算且.bit檔檔案大小排序最小的二十個人(20%)
- 作業驗收時間為12/12(三)以前上傳

# Nexys4的七段顯示器


- 不能同時讓八個七段顯示器顯示出不同的數字
- 利用視覺暫留,讓七段顯示器顯示數值
- · 課堂練習裡面的Code能提供想法
- · 接線部分可以參考.xdc檔






#### Install Vivado (1/9)

• 點選 Download Vivado Design Suite



#### Install Vivado (2/9)

• 點選Vivado HLx 2018.2:WebPACK and Editions



#### Install Vivado (3/9)

• 完善個人資料後下載(此範例不需要修改)

#### Download Center - Name and Address Verification U.S. Government Export Approval Taiwan, Province Of China U.S. export regulations require that your First Name, Last Name, Company Name and Shipping Address be verified before Xilinx can fulfill your download request. Please provide accurate and complete information. Phone . Addresses with Post Office Boxes and names/addresses with Non-Roman Characters with accents such as grave, tilde or colon are not supported by US export compliance systems Job Function\* Last Name\* Student Lin Primary Market\* Test and Measurement 10211250@gm.nttu.edu.tw CC University Address 1\* Sec. 1, University Road, Minxiong Township, Chiayi County 621, Taiwan TW

# Install Vivado (4/9)

· 點擊EXE檔開始安裝



	Welcome	Select Install Type
VIVADO PLA Editorra	We are glid you've choses Xilian as your platform development partner. This program can install the Yavedo Design Environment, Softwace Development Ket and Documentshion Novigabor.  Supported operating eyelens for Yavedo 2017.3 are:  - Windows 7.1: 64-bit  - Windows 10.0 Cenators Update: 64-bit  - Red 164: Enterprise Livius 6.6-6.9: 64-bit  - Cenation Livius 7.6-6.9: 64-bit  - Cenation Livius 6.6-6.9: 64-bit  - Cenation Livius 7.2-7: 3-64-bit  - SINKE Enterprise Livius 11.4: 64-bit  - SINKE Enterprise Livius 12.2: 64-bit  - Whentu Livius 16.04.2 LTS: 64-bit - Additional Library installation required  Note: 32-bit mechine support is now only available through HW Server standalone product installers  Note: This antallation program will not install cable drivers on Livius. This issue will need to be installed separately, with administrative privileges.  To reduce installation time, we recommend that you disable any auth-virus pothware before continuing.	Select Install Type  Floar solutional type and provide your Kilistorium user ID and personnel for authentications.  User Authentication.  Floar provide your Kilistorium according contained to download the imputed files.  If you don't have an account please seeds one. If you forgot your personnel, you can gust at here.  User ID colab.  Pairword.  © Download and Install Now
		Select your desired device and tool intellation options and the installer will download and install jout what is required. Download installation files will be seved for future will Foreign the deviced and installation files will be restricted to the options selected during this install. For access to all options later, choose "Download Full Image".  Download Full Image (Install Separately)  The installar will download an image containing all devices and tool options for later installation. Use this option if you wish to install a full image on a network drive or allow different users association, flexibility when installing
EXILINX	M. All rights suggested.  Perforences Such Next V Concell	Consumit © 1998-2017 Millers, Sociali meltri susurvol.

#### Install Vivado (5/9)

• 開始安裝



#### Install Vivado (6/9)

• 開始安裝



#### Install Vivado (7/9)

• 等待安裝





#### Install Vivado (8/9)

- USERNAME: colab
- •password:cocococo4\*
- •LICENSE:
- https://drive.google.com/file/d/1ddZw3QlqKx\_4s5ate7\_dDbikZX7GN5h-/view?usp=sharing

備註:請大家不要修改帳號相關資料

#### Install Vivado (9/9)

• 加入LICENSE

